# **ADVANCED ARCHITECTURE**

Annalisa Massini 2024-2025

Lecture 1

# **COURSE INFORMATION**

## **Course topics**

Three years ago, I started to change the focus of this course and I also changed its name.

At the moment, the course is more focused on architectures than on applications and notions of quantum computing are also introduced

The course will focus on:

- Advanced topics of computer architectures
  - Arithmetic circuits and their evaluation
  - Interconnection topologies for HPC and P&D systems and related communication problems
- Introduction to Quantum Computing, with particular regard to quantum arithmetic circuits

# Time, venue and course page

- **T1 room building E: Tuesday** 14:00-17:00 **Thursday** 11:00-13:00
- Lectures will be given mainly by using slides
- Exercises will be done by using the blackboard/tablet
- Course page is:

http://twiki.di.uniroma1.it/twiki/view/Cl/WebHome

- Use the course page to get information on the lessons and access the course material
- Register to course atlaflb on classroom using your Sapienza email (<u>surname.matricola@studenti.uniroma1.it</u>) to receive notices and additional material

5

of 44

### Exam

#### Exam will consist of:

- Written part
  - Two partial exams (Midterm + end-of-term) or a final exam that will consist in a written test with exercises
- Oral part
  - Oral exam or Presentation of one-two papers or Development and presentation of a project
  - NOTE that project topic and papers for presentation must cover one course topic and must be approved by the teacher

# Collaborative lessons (and exam)

- I would also like to introduce a form of collaborative teaching that could be a further alternative to the oral exam for students who volunteer to participate
- This will depend on how many students will take the course, so I/we will decide halfway how to organize some lessons and for which topics
- My idea is to organize groups of 2/3 people so that:
  - one group takes responsibility for preparing and presenting a lesson
  - another group takes responsibility for asking questions
  - and another one for preparing and doing exercises
  - (with the support of my slides and the material I have)
- In the meantime, you can look at the topics covered last year, keeping in mind that the sequence of the topics can be changed and not all the topics might be suitable for this organization

### Books

I will not use a single reference book

I will give you:

- Reference books for each topic of the course
- Lectures slides

The main books I will refer to are:

- Computer Architecture A Quantitative Approach J. L. Hennessy, D.A. Patterson – Morgan Kaufmann 5<sup>th</sup> Ed. 2011 and 6<sup>th</sup> Ed. 2019
- Dancing with qubits R.S. Sutor – Packt> - 2019

### Books

#### Some chapters from the following books:

Advanced Computer Architecture and Parallel Processing H. El-Rewini, M. Abd-El-Barr, John Wiley and Sons, 2005

**Parallel computing for real-time signal processing and control** *M. O. Tokhi, M. A. Hossain, M. H. Shaheed – Springer – 2003* 

Multicore and GPU Programming An IntegratedApproach G. Barlas – Morgan Kaufmann – 2014

**Parallel Computer Architecture: A Hardware/Software Approach** D.E. Culler, J. P. Singh, A. Gupta – Morgan Kaufmann – 1998

**Introduction to High Performance Computing for Scientists and Engineers** *G. Hager G. Wellein – CRC Press – 2011* 

**Programming Massively Parallel Processors** D.B. Kirk W. W. Hwu - Morgan Kaufmann – 2013

### **Course topics**

#### Part 1 – Architectures

- Overview of the Von Neumann architecture
- Circuits for arithmetic operations and circuit evaluation
- Number representations for Fast Arithmetic
- Motivation to parallel architectures and their classifications
- SIMD class: vector architecture and GPUs
- Sparse matrices: compact storage methods

### **Course topics**

#### Part 2 – Parallel architectures and quantum circuits

- Performance metrics and measurements for computer architectures evaluation
- MIMD class: interconnection networks and related problems
- Quantum Computing and quantum arithmetic circuits

# INTRODUCTION

The importance of high-performance architectures and their impact on computational science

### Introduction

- Traditional methods in science and engineering are:
  - To develop *theories* and *projects*
  - To execute experiments and
  - To build *systems*
- The realization of these tasks can be :
  - Too *difficult*  $\rightarrow$  wind tunnel
  - Too  $expensive \rightarrow$  crash testing
  - Too *slow* → the evolution of a galaxy
  - Too *dangerous* → drugs, toxic gas diffusion








Chlorine release, 2010 Jack Rabbit I Program

### Introduction

 Computers represent the fundamental tool for the simulation and can be seen both as a microscope and as a telescope with respect to space and to the time



#### Examples

- Model molecules in details
- Travel to the origin of the universe and study its evolution
- Provide weather forecasts or climate changes





### Introduction

Instruments as particle accelerator, telescopes, scanner, etc., produce big quantity of data

**Data** are elaborated by a computer and are:

- Reduced and transformed
- Represented and visualized

#### Objectives of **data elaboration** are:

- To understand the meaning of the produced data
- To develop new theories
- To verify different kind of phenomena






# **Computational Science**

- Computational science is concerned with:
  - Mathematical models
  - Quantitative analysis techniques
  - Computer elaboration
  - Analysis and solution of scientific problems
- Computational science involves:
  - The application of computer simulation
  - Different forms of computation (numerical analysis, theoretical computer science, etc.)
  - Problems in various scientific disciplines

 $\frac{dLs}{dt} = N * K_1 - (d_1 + r) * Ls + \delta_1$   $\frac{dLux}{dt} = \left(\frac{K_2}{1 + A * Ls 1^2}\right) * N - (d_2 + r) * Lux + \delta_2$   $Z = Z_1 + Z_2$   $Z_1 = K_3 * Lux$   $Z_2 = \iint_{0,0}^{2\pi,D} e^{-K_4 s} * Z_{i,j} ds$   $\frac{dLs1}{dt} = Ls * \left(1 - \frac{Ls}{\kappa_5}\right) * Z * \left(1 - \frac{Z}{\kappa_6}\right)$ (1)





# **Computational Science**

 The scientific computing approach is to gain understanding, mainly through the analysis of mathematical models implemented on computers

#### **Computational science:**

- Is different from theory and laboratory experiments, traditional forms of science and engineering
- Is now considered a third mode of science, besides theory and experimentation/observation





# **Computational Science**

- Scientists and engineers develop computer programs and application software, that model systems being studied
- These programs are run with various sets of input parameters



 In most cases, these models require massive amounts of calculations (usually floatingpoint numbers) that are executed on supercomputers or distributed computing systems



# FUNDAMENTALS OF QUANTITATIVE DESIGN AND ANALYSIS

Computer Architecture: A Quantitative Approach

J. L. Hennessy, D. A. Patterson - Morgan Kaufmann, 2012

#### **19** of 44

# Computer architectures evolution

• The dramatic growth rate in computer performance in the 20th century has been **fourfold** 

#### • First impact

- Significant enhancement of the capability available to computer users
- For many applications, the highest-performance microprocessors of today outperform the supercomputers of less than 20 years ago

#### Second impact

- New classes of computers
- In the 1980s: *personal computers* and *workstations* thanks to microprocessor
- Last two decades: smart cell phones and tablet computers
  - used as primary computing platforms instead of PCs
  - exploiting the *Internet* to access warehouses containing *tens of thousands of servers*, as they were a single gigantic computer

#### Third impact

- Improvement of semiconductor manufacturing (predicted by Moore's law) led to the dominance of microprocessor-based computers
  - Minicomputers, traditionally made from gate arrays, were replaced by servers made using microprocessors
  - Even *mainframe computers* and *high-performance supercomputers* are all collections of *microprocessors*
- The hardware innovations led to a renaissance in computer design, which emphasized both architectural innovation and efficient use of technology improvements
- By 2003, high-performance microprocessors were 7.5 times faster than what would have been obtained by relying solely on technology, including improved circuit design
- That is, 52% per year versus 35% per year

#### Fourth impact

- The hardware renaissance had impact on software development
  - In place of performance-oriented languages like C and C++, much more programming today is done in managed programming languages like Java and C#
  - Scripting languages like Python and Ruby, which are even more productive, gained in popularity
  - To maintain productivity, interpreters with just-in-time compilers and trace-based compiling are replacing the traditional compiler + linker
- Software deployment is changing as well: Software as a Service (SaaS) used over the Internet instead of software running locally
- The nature of applications is also changing: speech, sound, images, and video are becoming increasingly important, along with predictable response time that is so critical to the user experience

- At a certain point, the hardware renaissance seemed to be over
- In 2004 Intel canceled its high-performance uniprocessor projects and joined others in declaring that the road to higher performance would be via *multiple processors per chip* rather than via faster uniprocessors
- There has been a historic shift from relying solely on the instruction-level parallelism (ILP) to data-level parallelism (DLP) and thread-level parallelism (TLP)
- Now also the warehouse-scale computers and the request-level parallelism (RLP) need to be considered

**24** of 44

# GENERATION OF COMPUTERS AND CLASSES

# **Generations of Computers**

- The history of computer architecture is traditionally divided into **four generations** (basic logic technology):
  - **1 Vacuum tube** 1946-1957
- **2 Transistor** 1958-1964


4 - VLSI

 3 - Integrated circuits
Small scale integration - 1965 on Up to 100 devices on a chip
Medium scale integration - to 1971 100-3,000 devices on a chip
Large scale integration - 1971-1977 3,000 - 10<sup>5</sup> devices on a chip

Very large scale integration - 1978-1991 10<sup>5</sup> - 10<sup>8</sup> devices on a chip Ultra large scale integration - 1991-Over 10<sup>8</sup> devices on a chip


# **Architectural Trends**

4th generation - VLSI generation - presents a great architectural advance



### **Architectural Trends**

The strongest delineation in VLSI generation is the kind of parallelism exploited



- The changes described
  - have influenced the computer markets in this new century
  - And, at the same time, our vision of computing and computer applications has changed considerably
- Since the creation of the personal computer, there have been no changes as evident as they are today in the appearance of computers and in the way they are used
- These changes in computer use have led to five different computing markets, each characterized by different applications, requirements, and computing technologies

- Personal mobile device (PMD) is the term applied to a collection of wireless devices with multimedia user interfaces such as *cell phones, tablet computers,* and so on
- **Cost** is a prime concern determining the consumer price
- Energy efficiency is driven by both battery power and heat dissipation
- The memory can be a substantial portion of the system cost, and it is important to optimize memory size
- The importance of memory size translates to an emphasis on code size, since data size is dictated by the application

- <u>Desktop computing</u> spans from low-end netbooks, sold at low price, to high-end, heavily configured workstations that are more expensive
- Since 2008, more than half of the desktop computers made each year have been battery operated laptop computers
- The desktop market tends to be driven to optimize *price*-*performance*:
  - **performance** is measured primarily in terms of compute performance and graphics performance
  - price is what matters most to customers in this market, and hence to computer designers
- As a result, the newest, highest-performance and cost-reduced microprocessors often appear first in desktop systems

- Since the 1980s, the role of <u>servers</u> has grown
  - to provide larger-scale and more reliable file and computing services
  - replacing the traditional mainframe
- First key feature is **availability**:
  - most servers must operate seven days a week, 24 hours a day
  - a failure can be catastrophic consider, e.g., the servers running ATM machines for banks or airline reservation systems
- A second key feature is **scalability**:
  - In fact, server systems grow in response to an increasing demand for the services they support or an increase in functional requirements
- Finally, servers are designed for **efficient throughput**, and the overall performance of the server is what is crucial

- The growth of the class of computers called <u>clusters</u> is due to the growth of Software as a Service (SaaS) for many applications
  - Clusters are collections of desktop computers or servers connected by local area networks to act as a single larger computer
- The largest of the clusters are called warehouse-scale computers (WSCs), and tens of thousands of servers can act as one
  - Price-performance, power and availability are critical to WSCs
  - WSCs emphasize interactive applications, large-scale storage, dependability, and high Internet bandwidth
- Supercomputers or HPC systems are related to WSCs in that they are equally expensive
  - Supercomputers emphasize floating-point performance and run communication-intensive batch programs that can run for weeks

- <u>Embedded computers</u> are found in everyday machines: microwaves, washing machines, most printers, most networking switches, and all cars contain simple embedded microprocessors
- The ability to run third-party software is the dividing line between non-embedded and embedded computers, so as PMD is a different category with respect to embedded computers
- Although the range of computing power in the embedded computing market is very large, price is a key factor in the design of embedded computers
- Performance requirements do exist, of course, but the primary goal is often meeting the performance need at a minimum price, rather than achieving higher performance (at a higher price)

### **Classes of Parallelism and Parallel Architectures**

- Parallelism at multiple levels is now the driving force of computer design across all classes of computers, with energy and cost being the primary constraints
- There are basically two kinds of parallelism in applications:
  - **Data-Level Parallelism** (DLP) arises because there are many data items that can be operated on at the same time
  - **Task-Level Parallelism** (TLP) arises because tasks of work are created that can operate independently and largely in parallel

### **Classes of Parallelism and Parallel Architectures**

**Computer hardware** in turn can exploit these two kinds of application **parallelism** in four major ways:

- 1. Instruction-Level Parallelism exploits <u>data-level parallelism</u> at modest levels with compiler help using ideas like *pipelining* and at medium levels using ideas like *speculative execution*
- 2. Vector Architectures and Graphic Processor Units (GPUs) exploit <u>data-level parallelism</u> by applying a single instruction to a collection of data in parallel


### **Classes of Parallelism and Parallel Architectures**

Computer hardware in turn can exploit these two kinds of application parallelism in four major ways:

- 3. Thread-Level Parallelism exploits either <u>data-level parallelism</u> or <u>task-level parallelism</u> in a tightly coupled hardware model (shared memory systems) that allows for interaction among parallel threads
- 4. Request-Level Parallelism exploits parallelism among largely <u>decoupled tasks</u> specified by the programmer or the operating system


- These four ways for hardware to support the data-level parallelism and task-level parallelism go back to the 60s
- Michael Flynn studied the parallel computing efforts in the 60s, and introduced a taxonomy of computer architectures that is still the most common way of categorizing systems defining abbreviations we still use today
- He looked at the parallelism in the instruction and data streams called for by the instructions at the most constrained component of the multiprocessor, and placed all computers into one of four categories

- In Flynn's classification, machines are classified based on how many data items they can process concurrently and how many different instructions they can execute at the same time
  - Single Instruction, Single Data SISD
  - Single Instruction, Multiple Data SIMD
  - Multiple Instruction, Single Data MISD
  - Multiple Instruction, Multiple Data MIMD




Single Instruction stream, Single Data stream – SISD

- This category is the uniprocessor
- The programmer thinks of it as the standard sequential computer, but it can exploit instruction-level parallelism
- SISD architectures use ILP techniques such as superscalar and speculative execution




#### Single Instruction stream, Multiple Data stream - SIMD

- The same instruction is executed by multiple processors using different data streams
- SIMD computers exploit data-level parallelism by applying the same operations to multiple items of data in parallel
- Each processor has its own data memory, but there is a single instruction memory and control processor, which fetches and dispatches instructions
- Examples are:
  - vector architectures
  - GPUs



**Multiple Instruction stream, Single Data stream – MISD** 


- No commercial multiprocessor of this type has been built to date
- But there can be possible future realizations/applications



#### Multiple Instruction stream, Multiple Data stream – MIMD

- Each processor fetches its own instructions and operates on its own data, and it targets task-level parallelism
- MIMD computers can also exploit data-level parallelism, even if the overhead is likely to be higher than in a SIMD computer

Tightly coupled MIMD architectures exploit thread-level parallelism since multiple cooperating threads operate in parallel Loosely coupled MIMD architectures (cluster and warehouse-scale computers) exploit request-level parallelism - independent tasks can proceed in parallel with little need for communication or synchronization



# High performance computers

- 1961 IBM 7030 Stretch → 10<sup>6</sup> Flops/sec (megaFLOPS or MFLOPS)
  - scalar processors
- 1984 M-13 → 10<sup>9</sup> Flops/sec (gigaFLOPS or GFLOPS)
  - vector processors, shared memory
- 1997 ASCI Red → 10<sup>12</sup> Flops/sec (teraFLOPS or TFLOPS)
  - massive parallelism, distributed systems, message passing
- 2008 IBM Roadrunner Red → 10<sup>15</sup> Flops/sec (petaFLOPS or PFLOPS)
  - multicore processors, precision extension, fault tolerance

## High performance computers

- 2011 Fujitsu K → 10,5 petaFLOPS
- 2016 Sunway TaihuLight → 93 petaFLOPS
- 2018 Summit → 122 petaFLOPS
- 2020 Supercomputer Fugaku → 415 petaFLOPS
- 2023 Frontier → 10<sup>18</sup> Flops/sec (exaFLOPS or EFLOPS)

See https://www.top500.org/